


Welcome to the Firefly family! Our top priority is to give you the best experience and value from your purchase. Please carefully read through the manual to enjoy your new Firefly product.

SAFETY AND GENERAL INFORMATION

- For your safety, read manual and safety instructions before use.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use near flammable and explosive materials.
- When loading batteries, always check the polarity to ensure proper operation.
- If the light output becomes dim, replace the battery.
- Contact the manufacturer or his service agent or a similar qualified person if the product fails to function as stated on the packaging or the manual.
- Product is for indoor or outdoor use.

PRODUCT DETAILS



TECHNICAL SPECIFICATIONS:

Operating Voltage	3 x 1.5Vdc, Dry Batteries (AA)
Light Source	5W x 1 LED
Dimension	Ø 33.5 x 310 mm
Material	Powder Coated Aluminum
Accessories	Lanyard

PRODUCT FEATURES

- 3 Light modes – High, Low, and Strobe.
- Body is made of aluminum which can withstand outdoor activities.
- Includes lanyard which prevents the item from falling.
- Knurled design handle for easy grip.

HOW TO OPERATE THE UNIT

1. Loose the tail cap then put 3 x 1.5V dry batteries (AA).
2. Locate the switch. It can be found at the tail cap end of the unit.
3. Torch mode will be from HIGH → OFF → LOW → OFF → STROBE → OFF once the switch is pressed consecutively.

USAGE AND MAINTENANCE

- Make sure that the bezel, LED compartment, and the tail cap are tight before use.
- To maximize is lighting effect, make sure the lamp is clean.
- Do not use the item to strike hard material like stone or metal. The product can be damaged or deformed.
- To protect the validity of the warranty, never use the item aside from its intended purpose. The supplier disclaims all its responsibility for product damage or personal injury resulting from misuse.

ATTENTION WHEN CLEANING

- Make sure to remove the batteries before cleaning.
- Do not use chemicals and other materials that may harm the product. When cleaning, use a damp cloth.
- Do not immerse in water.

We would love to hear from you. For comments and suggestions, you can email us at info@fireflyelectric.com

CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.