


Welcome to the Firefly family! Our top priority is to give you the best experience and value from your purchase. Please carefully read through the manual to enjoy your new Firefly product.

SAFETY AND GENERAL INFORMATION

- For your safety, read manual and safety instructions before use.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use near flammable and explosive materials.
- When loading batteries, always check the polarity to ensure proper operation.
- If the light output becomes dim, replace the battery.
- Contact the manufacturer or his service agent or a similar qualified person if the product fails to function as stated on the packaging or the manual.
- Product is for indoor or outdoor use.

PRODUCT DETAILS



- ① Bezel
- ② LED Compartment
- ③ Handle
- ④ Tail Cap
- ⑤ Tail Switch
- ⑥ Adjustable Neck
- ⑦ Charger
- ⑧ Charge Indicator
- ⑨ Negative Terminal
- ⑩ Positive Terminal

TECHNICAL SPECIFICATIONS:

Operating Voltage	220V AC 50/60Hz
Battery Type	3.7Vdc Lithium Ion Rechargeable (2000mAh)
Light Source	6W x 1 LED
Charging Time	4 - 6 Hours
Dimensions	Ø 32 x 46 mm
Material	Powder Coated Aluminum
Accessories	Charger, Lanyard, Box, Battery

PRODUCT FEATURES

- 3 Light modes – High, Low, and SOS.
- Adjustable Beam – Wide and focused. Good for short or long distance.
- Made of aluminum.
- Equipped with plano-convex lens for better light distribution.

HOW TO OPERATE THE UNIT

1. Make sure the battery is fully charged before use.
2. Insert the battery on the battery compartment of the unit, be careful of the polarity.
3. Locate the switch. It can be found at the tail cap end of the unit.
4. Torch mode will be from HIGH → OFF → LOW → OFF → SOS → OFF once the switch is pressed consecutively.
5. Beam angle can be adjusted by extending the lamp's head. Pull the lamp head until it reaches the desired beam angle.

USAGE AND MAINTENANCE

- Make sure that the bezel, LED compartment and tail cap are secured before use.
- To ensure best lighting, make sure that the LED lens is clean.
- When charging, be careful with the polarity of the battery. Reverse polarity may easily damage the charger.
- To protect the validity of the warranty, never use the item aside from its intended purpose. The supplier disclaims all its responsibility for product damage or personal injury resulting from misuse.

ATTENTION WHEN CLEANING

- Make sure to remove the batteries before cleaning.
- Do not use chemicals and other materials that may harm the product. When cleaning, use a damp cloth.
- Do not immerse in water.

We would love to hear from you. For comments and suggestions, you can email us at info@fireflyelectric.com

CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.